


# Find the right size to get the perfect fit with your DEHNcare personal protective equipment.

## Protective clothing - How to take your measurements (cm):



- |                             |   |
|-----------------------------|---|
| <b>A</b> Body size:         | without shoes, from the top of your head to the soles of your feet      |
| <b>B</b> Chest measurement: | measure under your arms round the widest part of your chest             |
| <b>C</b> Waistband:         | measure around your waist with the tape measure snug but not digging in |
| <b>D</b> Hip size:          | measure with the tape measure around the widest part of the hips        |
| <b>E</b> Inside leg length: | measure from the crotch to the hemline                                  |
| <b>F</b> Sleeve length:     | measure from the top of the shoulder over the elbow to the wrist bone   |

## DEHNcare ArcFit HLP 63

### Standard men's sizes (cm)

Ordering size	48	50/52	52/54	56/58	58/60	62/64	64/66
	S	M	L	XL	2XL	3XL	4XL
Body size	166-178	170-182	174-188	178-190	182-194	184-196	188-200
Chest measurement	92-102	98-108	104-114	110-120	116-126	122-132	128-138
Waistband	80-90	86-96	92-102	98-108	104-114	110-120	116-126
Hip size	107	115	123	131	139	147	155
Inside leg length	79.5	81.5	83.5	85.5	86.5	87.5	88.5
Sleeve length	64	65.5	67	68.5	70	71.5	73