



LG-B60-VxR P3

LG-B60-V1R P3 001341750			
No.	Type ETI	Name	Pcs.
1	LG-B60-BEL-1	Holder	1
2	LG-V6R-B	Support	2
3	LG-V6R-KK	Support	2
4	LG-V6R-LN	Support	2
5	AST 4.8x9,5	Tapping screw	6
6	BBS-60/3	Busbar support	1
7	AS-SH 6x20	Screw M6x20 DIN912	2
8	AN-FSH 6	Nut flange serrat DIN6923 Zn	4
9	AS-SH 6x10	Screw M6x10 DIN912	2
10	AW-RE 6	Washer M6 DIN9021 Zn	2

LG-B60-V2R P3 001341752			
No.	Type ETI	Name	Pcs.
1	LG-B60-BEL-2	Holder	1
2	LG-V6R-B	Support	2
3	LG-V6R-KK	Support	2
4	LG-V6R-LN	Support	2
5	AST 4.8x9,5	Tapping screw	6
6	BBS-60/3	Busbar support	1
7	AS-SH 6x20	Screw M6x20 DIN912	2
8	AN-FSH 6	Nut flange serrat DIN6923 Zn	4
9	AS-SH 6x10	Screw M6x10 DIN912	2
10	AW-RE 6	Washer M6 DIN9021 Zn	2



LG-B60-V2R P4

001341754

LG-B60-V2 P4 001341704			
No.	Type ETI	Name	Pcs.
1	LG-B60-BEL-2	Holder	1
2	LG-V6R-B	Support	2
3	LG-V6R-KK	Support	2
4	LG-V6R-LN	Support	2
5	AST 4.8x9,5	Tapping screw	6
6	BBS-60/4	Busbar support	1
7	AS-SH 6x20	Screw M6x20 DIN912	3
8	AN-FSH 6	Nut flange serrat DIN6923 Zn	5
9	AS-SH 6x10	Screw M6x10 DIN912	2
10	AW-RE 6	Washer M6 DIN9021 Zn	2

